

# **ControlByWeb X-310 Driver**

# Installation and Usage Guide

Revision:3.0Date:Monday, July 10, 2017Authors:Alan Chow



# Contents

Overview	2
Features	3
Change Log	4
Important Notice	4
Driver Installation	4
Adding the driver to your project	5

## **Overview**

The X-310<sup>™</sup> is a full-featured, web-enabled, Ethernet I/O module with four, independent 1-Amp relays, four opticallyisolated digital inputs, support for up to four temperature or humidity sensors, and the ability to control up to 16 remote relays. It has non-volatile memory for logging, a real-time clock with support for NTP (time server) synchronization and an advanced full-calender scheduler which can be used to turn on/off relays at preset times. Its web-based user interface makes it easy to set-up and use.

The Chowmain ControlByWeb X-310 driver for Control4 integrates 4 Relays, 4 Inputs, exposes 4 temperature sensor values and more to Control4.



## **Features**

- 4 x relay outputs
- 4 x sensor inputs
  - NOTE Control4 polls the sensors. As such it may take upto 5 seconds for the input to respond. Do not use the inputs if timing is crucial.
- Exposes values to variables for programming
  - o Last Poll Time
  - Serial Number
  - Onboard Timestamp
  - o Internal Temperature
  - o Memory Power Up Flag
  - Device Power Up Flag
  - o Poss Loss Counter
  - Input 1 State
  - Input 2 State
  - Input 3 State
  - Input 4 State
  - o Relay 1 State
  - o Relay 2 State
  - Relay 3 State
  - o Relay 4 State
  - High Time 1
  - o High Time 2
  - o Raw Count 1
  - o Raw Count 2
  - Voltage Input
  - Voltage Input Alarm
  - o Units
  - o Sensor 1 Temp
  - o Sensor 2 Temp
  - o Sensor 3 Temp
  - o Sensor 4 Temp
  - o Sensor 1 Alarm
  - o Sensor 2 Alarm
  - o Sensor 3 Alarm
  - o Sensor 4 Alarm
  - o Count 1
  - o Count 2
  - Extra Variable 0
  - Extra Variable 1



- o Extra Variable 2
- o Extra Variable 3
- 0
- Programming Actions
  - Ability to clear memory flag
  - Ability to clear device flag
  - o Ability to clear power loss counter

# **Change Log**

#### Version #20160107 - 07-JAN-2016

• Fixed memory leak if device is offline.

Version #20151117 - 17-NOV-2015

• Development Begins

## **Important Notice**

This driver polls the unit once every 5 seconds. As such it may take upto 5 seconds for a response. It is not recommended for time critical applications such as motion sensing.

### **Driver Installation**

1. The driver you have downloaded will be in a zip file. Double click on this file to open it in your preferred zip program (WinZip, WinRar, etc.).



2. Extract the c4i file to the My Documents\Control4\Drivers directory. If you are using Windows 7 or 8 this will be extracted to the Libraries\Documents\Control4\Drivers directory.



3. You are now ready to add and configure the driver via the Composer Pro software.



## Adding the driver to your project

**IMPORTANT** – Before undertaking the installation of the driver please follow the licencing steps outlined at the end of this document.

- 1. Launch the Composer Pro application and connect to your project
- 2. In the 'System Design' page select the 'Search' tab on the right hand side.
- 3. Type in 'X-310' into the search bar

X-310		•
🗹 Local 🛛	🗹 Online 🛛 Cert	ified Only
All Device	Types 💌 🗔 All	Manufacturers 💌
Results	Sort by:	Relevance 💌
Controll	ByWeb X-310	
Controll ControlByW	•	X-310

- 4. Double click on the 'ControlByWeb X-310' driver to add it to your project
- 5. Highlight the 'ControlByWeb X-310' driver on the left hand side.
- 6. Enter in the IP address, username and password for the device.

Note: The driver will automatically come with the default username and password filled out.

IP Address	192.168.3.221
Username	admin
Password	webrelay




7. The driver will auto import the details. Once the details populate the screen then you are ready to add motorised/sensor devices and make the connections.

Last Poll Time	
Serial Number	n/a
Onboard Timestamp	n/a
Internal Temperature	n/a
Memory Power Up Flag	n/a
Device Power Up Flag	n/a
Power Loss Counter	n/a

8. Click on My Drivers on the right hand side.



9. Under Motorisation double click on the device type you want to use (note this will be the icon for your device).



- 10. Do the same for Sensor based devices.
- 11. Click on the Connections tab.



12. Highlight driver on the left hand side.



13. Bind the Relay to the device outlet is it connected to.

Control Outputs			
Input 1	Control	CONTACT_SENSOR	Output
🚺 Input 2	Control	CONTACT_SENSOR	Output
🚺 Input 3	Control	CONTACT_SENSOR	Output
📲 Input 4	Control	CONTACT_SENSOR	Output
👔 Relay 1	Control	RELAY	Output
👔 Relay 2	Control	RELAY	Output
👔 Relay 3	Control	RELAY	Output
👫 Relay 4	Control	RELAY	Output

14. Click on the File and Refresh Navigators. Congratulations you have set up the Control by Web driver.



# Licencing

Chowmain drivers require a valid licence to use the driver. Drivers can be purchased from our distributor <u>driverCentral</u> however all Chowmain drivers come with a 7 day trial. We recommend that prior to purchasing a driver that you test the driver out to ensure that it will work with your hardware and will meet your requirements. The licencing procedure is broken down into 4 steps. A summary of the steps are below along however we have also provided detailed steps if the summary is not sufficient.

#### **Summary**

- 1. Create your project on the driverCentral.io website (This will generate a specific token which you will use in the next step)
- 2. Download, install and activate the driverCentral cloud driver in your project (Only once per project. Use the token generated in step 1)
- 3. (Optional) To try a driver, simply download it and install it in your project
- 4. To purchase a driver:
  - a. On driverCentral, purchase a license and register it to your project
  - b. If the driver is not already installed in your project, download it and install it
  - c. If necessary, use the cloud driver's Action: "Check Drivers" to force licence download to the project.

#### **STEP 1 - Creating your project on driverCentral**

- 1. Visit <u>http://www.drivercentral.io</u>
- 2. Log into your driver Central dealer account.
- 3. Visit the Project Portal
- 4. Click on Create Project

ck on a project or create new project	Download Cloud Driver	Create Proje
Search in table		
Project Name 🗢	Status ≎	
	α	( <b>1</b> ) »



5. It will prompt you for a project name. Type in a meaningful name for your customer's project

Project Creation	
Project Name	
Enter Project Name	

- 6. Click on Create Project
- 7. Click on the project we just created to expand the project

		Create Projec
Search in table		
Project Name 🗢	Status ♦	
> Alan's House		
	«	<b>1</b> > »

8. Take note of the Project Token as this will be used in STEP 3 when we install the driverCentral cloud driver.

	Not Connected to Project	
Project Token: ABCDEFGHIJ	Last Communication: Not Connected	Connection Status:
	Not Connected	Not Connected




### **STEP 2 – Purchase driver licence**

- 1. Visit <u>https://www.drivercentral.io/chowmain-ltd/</u> and find the product/driver you want to purchase a licence for.
- 2. Click on the Add to Cart button



3. Click on the Shopping Cart icon in the top right corner and click on View cart



4. Confirm that your order is correct and click on Proceed to checkout

#### Proceed to checkout

5. Follow the prompts and click on Sib, ot , u Prder



- 6. This will take you to PayPal for payment.
- 7. Pay via PayPal. It will automatically return to the marketplace when confirmed.
- 8. You will now be at a page where you can see your purchased licence.





9. From here assign the licence to the project we created or if you did not follow that step create a new project

License Assignment for	2
Assign License to Existing Project	2
Select Existing Project:	
	_
New Project (enter project name below)	•
Or	·
Or	·
Or Create a new project	•
Or Create a new project Enter New Project Name	·

## STEP 3 - Install and activate the driverCentral cloud driver

NOTE: Only one instance of the driverCentral cloud driver installed per project. Do not install additional cloud drivers.

- 1. Visit <u>http://www.drivercentral.io</u>
- 2. Log into your driver Central dealer account.
- 3. Visit the Project Portal
- 4. Click on Download Cloud Driver

	Download Cloud Driver	Create Proj
Search in table		
Project Name ≑	Status ≎	
	« «	<b>1</b> > »

- 5. Copy the C4Z driver to My Documents\Control4\Drivers directory.
- 6. Add the driver to your project.



7. Click on the driver to view it's properties

Cloud Status	Please enter cloud project token below
Project Information	(1) Total, (0) Licensed, (0) Trials, (1) Expired, (0) Updates.
Driver Version	1001
Project Token	
	Project token from driverCentral.io project portal
Driver Actions	×
Debug Mode	Off v

- 8. Type in the project token we took note of in STEP 1.
- 9. Click on the Actions tab
- 10. Click on Check Drivers

#### **STEP 4 – Install Chowmain driver**

- 1. Install the Chowmain driver
- 2. You will notice that the Activation Status reflects a Licence Activated state.
- 3. Any driver that does not have a purchased licence will have a trial licence activated via the marketplace. Note that there is no way to reactivate the trial so please use wisely.
- 4. If you do not then press the Check Drivers action in the driverCentral Cloud driver again.

Activation Status	Update Available!!! License Activated	
Driver Version	1002	
Driver Information	Navigate to connections tab and make serial binding	
Automatic Updates	Off	~